


# Remote Control Setting

# Button

# Remarks



Press the "ON/OFF" button, the light goes to constant on/off mode, sensor is disabled.  
Press "Reset" "Sensor motion" button to quit from this mode and the sensor starts to work.




Press "Reset" button, all parameters are same as setting of DIP switch or factory settings.




Press "Sensor motion" button, the light quits from the constant on/ off mode,and the sensor starts to work (The latest setting stays in validity )



Press "DIM Test" button,the 1-10 V dimming works to test whether the 110Vdc dimming ports are connected properly.After 2s, it returns to the latest setting automatically.



Long press>3s,daylight priority mode will be switched to daylight threshold mode,with preset daylight value



Set occupany light level in range of 50%-100%,dim level is 5% each timepress Dim+/Dim-



Long press>3s,sensor will be switched to daylight priority mode;if preset daylight value is "Disable",sensor will stay in daylight threshold mode



Scene Options	Detection Area	Hold Time	Stand-by period	Stand-by dim level	Daylight Sensor	Induction model
QS1	100%	5min	10min	10%	30Lux	HS
QS2	100%	10min	30min	10%	Disable	HS
QS3	100%	20min	30min	10%	Disable	HS

Note: Detection area / Hold time /Stand-by period /Stand-by dim level / Daylight sensor can be adjusted by pressing the corresponding button.The latest setting will stay valid.



Press the "TEST 2S" button can enter the test mode any time. At the mode, the sensor parameters as below: Detection Area is 100%, Hold Time is 5s, Stand-by Dim Level is 10%, Stand-by Period is 0s, daylight sensor disable.This function only for testing. Quit the mode by pressing "RESET" or any other function buttons.



Press "HS" button to set the detection area to be high sensitive.  
Press "LS" button to set the detection area to be low sensitive.  
The adjustment bases on the "Detection Area"parameter you set.



Daylight Sensor  
Set up daylight threshold:  
5Lux/15Lux/30Lux/50Lux/100Lux/150Lux/ Disable



Stand-by period  
Set up stand-by time: 0s/10s/1min/3min/5min/10min/30min/+0o



Hold time  
Set up hold time: 5s/30s/1min/3min/5min/10min/20min/30min



Stand-by dim level  
Set up stand-by dim level: 10%/20%/30%/50%




Detection Area  
Set up detection area: 25%/50%/75%/100%



Remote Distance  
Toggle botton can set the remote distance of remote control and sensor.



Transmitting angle of remote control against different setting, please choose right button based on mounting height of sensor.



### FACTORY SETTING

Detection area	Hold Time	Stand-by Period	Daylight Sensor
100%	5s	0s	Disable

### FAQ

Question	Cause	Remedy
The load will not illuminate	Incorrect daylight sensor setting selected.	Adjust setting.
	Load has failed.	Replace load.
	Power is switched off.	Switch on.
The load is permanently illuminated.	Continuous movement in the detection area.	Check detection area setting.
	The lamp (containing sensor) is installed in an area too close to reflective surfaces, i.e. metal, glass or concrete walls.	1, Make sure installation area suitable with at least 30cm space between lamp and surrounding reflective surfaces. 2, Reduce sensitivity (detection area).
The load will not illuminate despite movement.	Speed of moving object is not in the range of 0.3-1m/s or the detection radius is too small.	Check detection area setting.