

Item no. 750-460
 4-channel analog input; For Pt100/RTD resistance sensors

Color:

This analog input module directly connects to Pt resistance sensors.
 Two-wire sensors can be connected.
 The module automatically linearizes the entire temperature range. A sensor error (short circuit, line break or measurement range overflow) is indicated by a red LED.

