
EIB-slave


Slavemodul for Glamox ovner serie H40/H60 Regulated by 3,5-5 Volt.

EIB-slave module for Glamox heating.

EIB-slave module for Glamox heating appliances may be controlled by the universal interface US/U 2.2 (two channels) and US/U 4.2 (four channels). When a signal voltage in the range of 3,5-5 volt is applied to the EIB-slave input wire, the heater will switch on and will continue to heat as long as the signal voltage is present.

The US/U 2.2 and US/U 4.2 device is usually regulated by a room thermostat.





Glamox[®] Heating